

---

## Test Procedure for

# SAMPLING FLEXIBLE DELINEATOR AND OBJECT MARKER POSTS



**TxDOT Designation: Tex-737-I**

**Effective Date: March 2008**

---

## 1. SCOPE

- 1.1 This test method outlines the procedure for taking samples of flexible delineator and object marker posts.
- 

## 2. SAMPLING

- 2.1 An authorized representative of the Department must select samples.
- 2.2 Take samples at the jobsite or at an approved Department stocking location prior to shipment to the jobsite.
- 

## 3. PROCEDURES

- 3.1 Select a sample consisting of a minimum of 3 flexible posts from each lot or shipment of a particular type or size.
- 3.2 Select samples at random that are representative of the materials supplied.
- 

## 4. TAGGING/LABELING, DOCUMENTING, AND SHIPPING

- 4.1 Follow the procedures detailed in Tex-701-I.
- 4.2 Tag or mark each sample in a non-destructive manner with the name of the flexible post, manufacturer's name, and quantity represented by the sample.
- 4.3 Complete [Form 202](#) with all information pertinent to samples.
- 4.4 Wrap bundle to prevent damage in transit.
- 

## 5. ARCHIVED VERSIONS

- 5.1 Archived versions are available.
-